



Easy Refill Kits



G & G Kit

Suits

No.of fills

Canon		
NR-C1001BK	Canon BC-01/02/20/23, BX-02, BC-24bk, BCI3ebk, BC-21bk, BC-03, BX-03, BCI-3/5/6bk, BCI-3/3e photo bk	1 x 30ml
NR-C1011CMY	Canon BC-05/06, BC-21C/24C, BCI-3/3e/5/6/8CMY	3 x 10ml
NR-C1012PH	Canon BC-22/22e	3 x 10ml
NR-C1013PHCM	Canon BCI-3/3e/5/6/8PC/PM	2 x 10ml

Epson		
NR-E1001BK	All Epson Black Cartridges *	1 x 30ml
NR-E1011CMY	All Epson 3 Colour Cartridges *	3 x 10ml
NR-E1012 PH	All Epson 2 Colour photo Cartridges *	2 x 10ml
Chip Resetter	Chip resetter for Epson CHIP cartridges	

*** Chip resetter required to fill chip cartridges. Refer to page 1 for listing**

HP		
NR-H1001BK	HP-6650, 51626, 51633, 6628	1 x 30ml
NR-H1002BK	HP-51645A, 6614, 6615, 8727, 6656, 51640A, 51629	1 x 30ml
NR-H1011CMY	HP-51625, 51641, 1823, 6625, 6578, 51649, 8728, 51629	3 x 10ml
NR-H1015BKPBCM	HP-6658, 1816	3 x 10ml

Lexmark		
NR-L1001BK	Lexmark 1380620, 12A1145, 1382050, 15M0125, 16G0055, 13620, 10N01217, 10N0016, Brother IN-700, LC-11BK	1 x 30ml
NR-L1002BK	12A1970, 12A1975, 17G0050, 17G0055, 15M0100, 1361400, 1300HC, 13400	1 x 30ml
NR-L1011CMY	17G0060, 12A1980, 13619, 15M0120, 1382060, 10N0227, 10N0026, 83, Brother IN-710, 11C	3 x 10ml
NR-L1012BKCM	1361760, 12A1990, 12A1170	3 x 10ml

Universal		
NR-T3102BK	Refills all Black inkjet Cartridges including HP, Epson, Canon, Lexmark, Brother, Xerox and Sharp Inkjet Cartridges	4 x 30ml
NR-T3111C.M.Y	Refills all Color inkjet Cartridges including HP, Epson, Canon, Lexmark, Brother, Xerox and Sharp Inkjet Cartridges	4 x 30ml

