

MICROJET IMAGING

INKJET CARTRIDGES

Item Code	Compatible for	Printer Models (for use on)	Color
-----------	----------------	------------------------------	-------



EPSON CARTRIDGES



ME-025	S020025	Epson Stylus 400/ 800/800+/1000/1000+; MJ-400/ 500/ 1000/ 1100/ 450/ 1010/ 1050.	BLACK
ME-034	S020034	Epson MJ- 900C/910C/700V/V2C/5000C/5100C;Stylus Color;Stylus Pro/ Pro XL/Pro XL+	BLACK
ME-036	S020036	Epson MJ- 900C/910C/700V/V2C/5000C/5100C;Stylus Color;Stylus Pro/ Pro XL/Pro XL+	C/M/Y
ME-047	S020047	Epson Stylus Color200/ II/Is;Stylus200/ 820, MJ-500C/ 510C/ 510CS/ 800C	BLACK
ME-049	S020049	Epson Stylus Color II/Is/1500; Epson MJ-500C/ 800C/ 850K/1500/ 1500K/3000C /3000CU	C/M/Y
ME-093/ME-T050+	S020093/T050+	Epson Stylus Color 400/500/600;Stylus Photo700/710/ IP-100/PT-100/PM-680C / PM700C/ PM-750C/ PM-2000C Epson MJ-810C/830C/830CS	BLACK
ME-089/ME-T052+	S020089/T052+	Epson Stylus Color 400/ 600/ 800/ 850/ 1520/ Epson MJ-830C/ 830CS/ 930C/ 6000C	C/M/Y
ME-097	S020097	Epson Stylus Color 200 / 500;Epson MJ-500/510C/510CS/610CS/810CS	C/M/Y
ME-108/ME-T051+	S020108/T051+	Epson Stylus Color 800/ 800N/ 850/ 1520;Epson MJ-930C/ 6000C	BLACK
ME-110/ME-T053	S020110/T053	Epson Stylus Photo 700/710/EX/EX2/EX3;; IP-100	5 COLOR
ME-138	S020138	Epson Stylus Color 300	C/M/Y BK
ME-187/ME-T050+	S020187/T050+	Epson Stylus Color 440/ 460/ 640/ 660/ 670; Photo 720/ 750/ 1200	BLACK
ME-189/ME-T051+	S020189/T051+	Epson Stylus Color 740/ 760/ 840/ 1160; SCA n 2000/ 2500	BLACK
ME-191/ME-T052+	S020191/T052+	Epson Stylus Color 440 / 460 / 640 / 660 / 670/ 740 / 760/ 860/ 1160, Scan 2000/2500	C/M/Y
ME-193/ME-T053	S020193/T053	Epson Stylus Photo 720/ 750 Epson PM-770C	5 COLOR
ME-T001	T001	Epson Stylus Photo 1200 Epson Stylus PM-3000C	5 COLOR
ME-T003	T003	Epson Stylus Color 900/ 900N/ 900G/ 980/ 980N	BLACK
ME-T005	T005	Epson Stylus Color 900/ 900N/ 900G/ 980/ 980N	C/M/Y
ME-T007	T007	Epson Stylus Photo 780; 790; 870; 875; 875DC; 890; 895; 915;1270;1280;1290;	BLACK
ME-T008	T008	Epson Stylus Photo 780; 785EPX; 870; 875DC/ 790/ 890/ 915	5 COLOR
ME-T009	T009	Epson Stylus Photo 1270;1280;1290	5 COLOR
ME-T013/T050+	T013/T050+	Epson Stylus Color 480 / 580, Epson Stylus C20, C20SX/UX, C40, C40SX/UX	BLACK
ME-T014/T052+	T014/T051+	Epson Stylus Color 480 / 580, Epson Stylus C20, C20SX/UX, C40, C40SX/UX	C/M/Y
ME-T015	T015	Epson Stylus Photo 2000P	BLACK
ME-T016	T016	Epson Stylus Photo 2000P	5 COLOR
ME-T017	T017	Epson Stylus Color 680; 777; 685	BLACK
ME-T018	T018	Epson Stylus Color 680; 777; 685	C/M/Y
ME-T019-T051+	T019-T051+	Epson Stylus Color 880 / 880i / 83	BLACK
ME-T020-T052+	T020-T052+	Epson Stylus Color 880 / 880i / 83	C/M/Y
ME-T026	T026	Epson Stylus Photo 810 / 820 / 830 / 925 / 935	BLACK
ME-T027	T027	Epson Stylus Photo 810 / 820 / 830 / 925 / 935	5 COLOR
ME-T028	T028	Epson Stylus Color C60 /C61/ CX3100	BLACK
ME-T029	T029	Epson Stylus Color C60 / C61/ CX3100	C/M/Y
ME-T0321	T0321B	Epson Stylus C70/ C80, C82, CX5100, CX5200, CX5300	BLACK
ME-T0322	T0322C	Epson Stylus C70/ C80	CYAN
ME-T0323	T0323M	Epson Stylus C70/ C80	MAGENTA
ME-T0324	T0324Y	Epson Stylus C70/ C80	YELLOW

Item Code	Compatible for	Printer Models (for use on)	Color
EPSON CARTRIDGES			
ME-T0341	T0341B	Epson Photo 2100 / 2200	BLACK
ME-T0342	T0342C	Epson Photo 2100 / 2200	CYAN
ME-T0343	T0343M	Epson Photo 2100 / 2200	MAGENTA
ME-T0344	T0344Y	Epson Photo 2100 / 2200	YELLOW
ME-T0345	T0345PC	Epson Photo 2100 / 2200	PC
ME-T0346	T0346PM	Epson Photo 2100 / 2200	PM
ME-T0347	T0347PB	Epson Photo 2100 / 2200	PB
ME-T0348	T0348MBK	Epson Photo 2100 / 2200	MBK
ME-T036	T036	Epson Stylus C42SX, C42UX,	BLACK
ME-T037	T037	Epson Stylus C42SX, C42UX,	COLOR
ME-T038	T038	Epson Stylus C41SX, C41UX, C43UX, C45	BLACK
ME-T039	T039	Epson Stylus C41SX, C41UX, C43UX, C45	COLOR
ME-T040	T040	Epson stylus C62	BLACK
ME-T041	T041	Epson stylus C62	C/M/Y
ME-T0422	T0422C	Epson stylus C82, CX5100, CX5200, CX5300	CYAN
ME-T0423	T0423M	Epson stylus C82, CX5100, CX5200, CX5300	MAGENTA
ME-T0424	T0424Y	Epson stylus C82, CX5100, CX5200, CX5300	YELLOW
ME-T0461	T0461	Epson stylus C63 / C65 / C83 / CX6300 / CX6500	NEW BLACK
ME-T0472	T0472	Epson stylus C63 / C65 / C83 / CX6300 / CX6500	NEW COLOR
ME-T0473	T0473	Epson stylus C63 / C65 / C83 / CX6300 / CX6500	NEW MAGENTA
ME-T0474	T0474	Epson stylus C63 / C65 / C83 / CX6300 / CX6500	NEW YELLOW
ME-T0491	T0491	Epson stylus Photo R210/ R310 /RX510	NEW BLACK
ME-T0492	T0492	Epson stylus Photo R210/ R310 /RX510	NEW CYAN
ME-T0493	T0493	Epson stylus Photo R210/ R310 /RX510	NEW MAGENTA
ME-T0494	T0494	Epson stylus Photo R210/ R310 /RX510	NEW YELLOW
ME-T0495	T0495	Epson stylus Photo R210/ R310 /RX510	NEW PC
ME-T0496	T0496	Epson stylus Photo R210/ R310 /RX510	NEW PM
ME-T0540	T0540GO	Epson stylus Photo R800	NEW GO
ME-T0541	T0541PBK	Epson stylus Photo R800	NEW PBK
ME-T0542	T0542C	Epson stylus Photo R800	NEW CYAN
ME-T0543	T0543M	Epson stylus Photo R800	NEW MAGENTA
ME-T0544	T0544Y	Epson stylus Photo R800	NEW YELLOW
ME-T0547	T0547R	Epson stylus Photo R800	NEW RED
ME-T0548	T0548MBK	Epson stylus Photo R800	NEW MBK
ME-T0549	T0549B	Epson stylus Photo R800	NEW BLACK
ME-T0561	T0561	Epson stylus Photo RX430	NEW BLACK
ME-T0562	T0562	Epson stylus Photo RX430	NEW CYAN
ME-T0563	T0563	Epson stylus Photo RX430	NEW MAGENTA
ME-T0564	T0564	Epson stylus Photo RX430	NEW YELLOW
ME-Resetter	NE-Super Star	Chip Resetter for Epson CHIP cartridges	

Item Code	Compatible for	Printer Models (for use on)	Color
EPSON LARGE FORMAT CARTRIDGES			
ME-118	S020118	Epson Stylus Color 3000; Epson Stylus Pro 5000	BLACK
ME-122	S020122	Epson Stylus Color 3000; Epson Stylus Pro 5000	CYAN
ME-126	S020126	Epson Stylus Color 3000; Epson Stylus Pro 5000	MAGENTA
ME-130	S020130	Epson Stylus Color 3000; Epson Stylus Pro 5000	YELLOW
ME-T407Bk	T407	Epson Stylus Pro 9000	BLACK
ME-T408Y	T408	Epson Stylus Pro 9000	YELLOW
ME-T409M	T409	Epson Stylus Pro 9000	MAGENTA
ME-T410C	T410	Epson Stylus Pro 9000	CYAN
ME-T411LM	T411	Epson Stylus Pro 9000	Light - M
ME-T412LC	T412	Epson Stylus Pro 9000	Light - C
ME-T460B	T460	Epson Stylus Pro 7000/PM-7000C	BLACK
ME-T461Y	T461	Epson Stylus Pro 7000/PM-7000C	YELLOW
ME-T462M	T462	Epson Stylus Pro 7000/PM-7000C	MAGENTA
ME-T463C	T463	Epson Stylus Pro 7000/PM-7000C	CYAN
ME-T464LM	T464	Epson Stylus Pro 7000/PM-7000C	Light-M
ME-T465LC	T465	Epson Stylus Pro 7000/PM-7000C	Light-C
ME-T474Bk	T474	Epson Stylus Pro 9500	BLACK
ME-T475Y	T475	Epson Stylus Pro 9500	YELLOW
ME-T476M	T476	Epson Stylus Pro 9500	MAGENTA
ME-T477C	T477	Epson Stylus Pro 9500	CYAN
ME-T478LM	T478	Epson Stylus Pro 9500	Light-M
ME-T479LC	T479	Epson Stylus Pro 9500	Light-C
ME-T480Bk	T480Bk	Epson Stylus Pro 7500	BLACK
ME-T481Y	T481Y	Epson Stylus Pro 7500	YELLOW
ME-T482M	T482M	Epson Stylus Pro 7500	MAGENTA
ME-T483C	T483C	Epson Stylus Pro 7500	CYAN
ME-T484LM	T484LM	Epson Stylus Pro 7500	Light-M
ME-T485LC	T485LC	Epson Stylus Pro 7500	Light-C
ME-T0499BK	T499201	Epson Stylus Pro 10000/10600	BLACK
ME-T0500Y	T500201	Epson Stylus Pro 10000/10601	YELLOW
ME-T0501M	T501201	Epson Stylus Pro 10000/10602	MAGENTA
ME-T0502C	T502201	Epson Stylus Pro 10000/10603	CYAN
ME-T0503LM	T503201	Epson Stylus Pro 10000/10604	Light-M
ME-T0504LC	T504201	Epson Stylus Pro 10000/10605	Light-C
ME-T5431PBK	T5431	Epson Photo Pro 9600 / 7600 / 4000	Photo-Black
ME-T5432C	T5432	Epson Photo Pro 9600 / 7600 / 4000	CYAN
ME-T5433M	T5433	Epson Photo Pro 9600 / 7600 / 4000	MAGENTA
ME-T5434Y	T5434	Epson Photo Pro 9600 / 7600 / 4000	YELLOW
ME-T5435LC	T5435	Epson Photo Pro 9600 / 7600 / 4000	Light-C
ME-T5436LM	T5436	Epson Photo Pro 9600 / 7600 / 4000	Light-M
ME-T5437LBK	T5437	Epson Photo Pro 9600 / 7600 / 4000	Light-BK
ME-T5438MBK	T5438	Epson Photo Pro 9600 / 7600 / 4000	Matte-BK
ME-T557	T557	Epson PictureMate Print Pack	B/C/M/Y/LC/L M