Epson Inkjet Compatibility Chart	SO20034 Black ink Tank	SO20036 Colour Ink Tank	SO20047 Black ink Tank	SO20049 Colour Ink Tank	SO20062 Black ink Tank	SO20066 Colour Ink Tank	SO20097 Colour Ink Tank	SO20138 4 Colour Ink Tank	T008 Colour Ink Tank	T009 Colour Ink Tank	T013 Black ink Tank	T014 Colour Ink Tank	T015 Black ink Tank	T016 Colour Ink Tank	T017 Black ink Tank	T018 Colour Ink Tank	T019 Black ink Tank	T020 Colour Ink Tank	T026 Black ink Tank	T027 Colour Ink Tank	T028 Black ink Tank	T029 Colour Ink Tank	T038 Black ink Tank	T039 Colour Ink Tank	T050 Black ink Tank	T051 Black ink Tank	T052 Colour Ink Tank	T053 Colour Ink Tank	T0321 Black ink Tank	T0322 Cyan Ink Tank	T0323 Magenta Ink Tank	T0324 Yellow Ink Tank	T0422 Cyan Ink Tank	T0423 Magenta Ink Tank	T0424 Yellow Ink Tank	T0461 Black ink Tank	T0472 Cyan Ink Tank	T0473 Magenta Ink Tank	T0474 Yellow Ink Tank	T0491 Black ink Tank	T0492 Cyan Ink Tank	T0493 Magenta Ink Tank	T0494 Yellow Ink Tank	T0495 Light Cyan Ink Tank	T0496 Light Magenta Ink Tank	T0540 Gloss Optimiser Ink Tank	T0541 Photo Black Ink Tank	T0542 Cyan Ink Tank	T0543 Magenta Ink Tank	T0544 Yellow Ink Tank	T0547 Red Ink Tank	T0548 Matte Black Ink Tank	T0549 Blue Ink Tank	T0561 Black Ink Tank	T0562 Cyan Ink Tank	T0563 Magenta Ink Tank	T0564 Yellow Ink Tank	T0557 Photo Ink Cartridge
PictureMate																																																										●
Colour Pro / Pro XL	●	●																																																								
Colour Pro XL+	●					●																																																				
Colour C20UX											●	●																																														
Colour C40SX/UX											●	●																																														
Colour C41SX/UX																							●	●																																		
Colour C43SX/UX																							●	●																																		
Stylus C45																							●	●																																		
Colour C60																					●	●																																				
Colour C61																					●	●																																				
Stylus C63																																				●	●	●	●																			
Stylus C65																																				●	●	●	●																			
Stylus C70																													●	●	●	●																										
Stylus C80																													●	●	●	●																										
Stylus C82																													●				●	●	●																							
Stylus C83																																				●	●	●	●																			
Stylus C85																																				●	●	●	●																			
Colour 200			●				●																																																			
Photo R210																																								●	●	●	●	●	●													
Colour 300								●																																																		
Photo R310																																								●	●	●	●	●	●													
Colour 400																									●		●																															
Photo RX430																																																						●	●	●	●	
Colour 440																									●		●																															
Colour 460																									●		●																															
Colour 480											●	●																																														
Colour 500							●																		●																																	
Photo RX510																																								●	●	●	●	●	●													
Colour 580											●	●																																														
Colour 600																									●		●																															
Photo RX630																																								●	●	●	●	●	●													
Colour 640 / 660																									●		●																															
Colour 670																									●		●																															
Colour 680															●	●																																										
Photo 700																									●			●																														
Photo 720																									●			●																														
Colour 740																										●	●																															
Colour 760																										●	●																															
Colour 800																										●	●																															
Photo R800																																														●	●	●	●	●	●	●	●					

Epson Inkjet Compatibility Chart	SO20025 Black ink Tank	SO20034 Black ink Tank	SO20036 Colour Ink Tank	SO20047 Black ink Tank	SO20049 Colour Ink Tank	SO20062 Black ink Tank	SO20066 Colour Ink Tank	SO20097 Colour Ink Tank	SO20138 4 Colour Ink Tank	T001 Colour Ink Tank	T003 Black ink Tank	T005 Colour Ink Tank	T007 Black ink Tank	T008 Colour Ink Tank	T009 Colour Ink Tank	T013 Black ink Tank	T014 Colour Ink Tank	T015 Black ink Tank	T016 Colour Ink Tank	T017 Black ink Tank	T018 Colour Ink Tank	T019 Black ink Tank	T020 Colour Ink Tank	T026 Black ink Tank	T027 Colour Ink Tank	T028 Black ink Tank	T029 Colour Ink Tank	T038 Black ink Tank	T039 Colour Ink Tank	T050 Black ink Tank	T051 Black ink Tank	T052 Colour Ink Tank	T053 Colour Ink Tank	TO321 Black ink Tank	T0322 Cyan Ink Tank	T0323 Magenta Ink Tank	T0324 Yellow Ink Tank	T0341 Photo Black ink Tank	T0342 Cyan Ink Tank	T0343 Magenta Ink Tank	T0344 Yellow Ink Tank	T0345 Light Cyan Ink Tank	T0346 Light Magenta Ink Tank	T0347 Light Black Ink Tank	T0348 Matte Black Ink Tank	T0422 Cyan Ink Tank	T0423 Magenta Ink Tank	T0424 Yellow Ink Tank	T0461 Black ink Tank	T0472 Cyan Ink Tank	T0473 Magenta Ink Tank	T0474 Yellow Ink Tank	T0491 Black ink Tank	T0492 Cyan Ink Tank	T0493 Magenta Ink Tank	T0494 Yellow Ink Tank	T0495 Light Cyan Ink Tank	T0496 Light Magenta Ink Tank
Photo 810																								●	●																																	
Colour 820				●	●																																																					
Photo 830 / 830U																								●	●																																	
Colour 850																															●	●																										
Colour 860																															●	●																										
Photo 870													●	●																																												
Colour 880																						●	●																																			
Photo 890													●	●																																												
Photo 895													●	●																																												
Colour 900											●	●																																														
Photo 915													●	●																																												
Photo 925																								●	●																																	
Photo 935																								●	●																																	
Photo 980											●	●																																														
Stylus 1000/+	●																																																									
Colour 1160																															●	●																										
Photo 1200										●																				●																												
Photo 1270													●		●																																											
Photo 1290													●		●																																											
Stylus 1500					●	●																																																				
Stylus CX1500																												●	●																													
Colour 1520																															●	●																										
Photo 2000P																		●	●																																							
Stylus 2100																																						●	●	●	●	●	●	●	●													
Colour CX3100																										●	●																															
Stylus CX5100																																		●												●	●	●										
Stylus CX5300																																		●												●	●	●										
Stylus CX6500																																																	●	●	●	●						